


ADJUSTING TIME ZONE

KNIGHT-SWIFT GUIDE FOR TROUBLESHOOTING GALAXY TAB ACTIVE 2, 3, 5'S


1 Tap the “i” icon at the bottom left.




2 Tap Settings.




3 Scroll to the bottom (Swipe Up).



4 Tap Date and time.



5 Automatic date and time is enabled by default. To further adjust, toggle switch.



6 Success! Time zone can now manually be adjusted.

