


# ADJUSTING FONT SIZE

KNIGHT-SWIFT GUIDE FOR TROUBLESHOOTING GALAXY TAB ACTIVE 2, 3, 5'S


**1** Tap the "i" icon at the bottom left.



**2** Tap Settings.




**3** Tap Display.



**4** If prompted, toggle switch to allow permission, then tap back arrow.



**5** Swipe up (scroll to the bottom).



**6** Use lever at the bottom to adjust font size as needed (this will affect all apps, such as KT Mobile, Pointe, Geotab, etc.)

