


ADJUSTING BRIGHTNESS

KNIGHT-SWIFT GUIDE FOR TROUBLESHOOTING GALAXY TAB ACTIVE 2, 3, 5'S


1 Tap the "i" icon at the bottom left.



2 Tap Settings.




3 Tap Display.



4 If prompted, toggle switch to allow permission, then tap back arrow.



5 Disable Auto Brightness, drag brightness level to preferred setting, and set Screen Timeout to preferred setting.



6 Once complete, adjusted brightness settings should look like the example below.

