

REFRESHING/ RESTARTING APPS

KNIGHT-SWIFT GUIDE FOR TROUBLESHOOTING GALAXY TAB ACTIVE 2, 3, 5'S

1

Press the **Recents Key** (physical button on the display, at the bottom right-hand corner).




2

All open apps will appear.



3

On the app you would like to refresh/restart, **Swipe up**.



4

Success! Re-open the app to reveal it has been refreshed. (If app still appears frozen or not updating, next attempt reset, or re-install app.)

